

DRIVEN

TM

DRWC4.3

TROUBLESHOOTING

Troubleshooting suggestions below if you are experiencing any issues.

1. With the RV unit connected to the tow vehicle, driving lights on, and the monitor connected, open the driver's door or with window rolled down, try to pair the monitor up by pressing the K3 button on the monitor. If this does not work, try step #2.

2. With the RV unit connected to the main town vehicle and the driving lights on, use a 2nd vehicle to power up the monitor at a closer proximity to the rear of the RV camera or use a portable battery source to power up the RV monitor such as a battery back to get the monitor closer to the RV camera for pairing.

3. If neither one of these steps work, disconnect the tow vehicle 7-way connector from the RV to tow vehicle. Then completely disconnect the 12V battery ground and positive terminals from the RV for 1 minute. Reconnect the battery and try step number 1 or 2 again.

Once the camera and monitor are paired up, they will function as normal as the camera will be looking for the same digital signature for the most recently paired monitor every time.